

Erebus Instructions

This device will only take a 2gig micro sd card or less. It has to be formatted in Fat16.

The Erebus will not recognize games in folders so no folders are allowed on the sd card.

The Erebus will display games in the old dos 8.3 format, so please rename your games to 8.3 format. If you don't rename your games it will load them but you will not be able to fit as many games on your sd card. To load the menu type "load" or "load"

To use the menu press the up or down arrow keys to select a game then press enter to load. Use the left or right arrow keys to move between pages.

There is a reset button just under the sd card slot so you don't have to remove the power jack on the oric.

At present the erebus will only load games that work on an oric atmos, so any games that only run on an oric 1 will not work. The Erebus has a Atmos rom image in it.

If you use a lead longer than 15cm it will cause lag on the oric so please use the lead provided.

Last but not least Enjoy.

Thanks for your custom

S. Gould owner of 8bit-Tronics.